



# BOARDWALK ARCADE

The Smallest  
Fully Functional  
Arcade Game

INCLUDES: 1 GAME,  
3 AAA BATTERIES,  
1 BASE, INSTRUCTIONS

## DEMO-PLAY MODE:

The World's Smallest™ Boardwalk Arcade game comes shipped in the Demo Mode. After removing the game from the package, please follow the FULL GAME PLAY MODE instructions below.

## ACTIVATE FULL GAME-PLAY MODE:




COLORS AND STYLES  
MAY VARY

## RESETTING GAME:

To reset Tiny Arcade turn On/Off switch to Off position. Use a Phillips Head screwdriver to remove screw to open battery door. Replace batteries. Reattach cover as indicated and reattach door. Turn the On/Off switch to On position and start new game.

## HOW TO CHANGE THE BATTERIES:



**WARNING:**  
CHOKING HAZARD-Small parts.  
Not for children under 3 years.

## WARNING. BATTERY SAFETY INFORMATION

In exceptional circumstances, batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Do not use rechargeable batteries.
- Do not attempt to recharge non-chargeable batteries.
- Do not mix alkaline, standard (carbon-zinc) and/or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only use batteries of the same or equivalent type as recommended.
- Insert batteries with the correct polarity.
- Remove exhausted batteries from the product.
- Do not short-circuit the supply terminals.
- Dispose of batteries safely.
- Do not dispose of batteries in fire. Batteries may explode or leak.
- Sometimes a build-up of static electricity (from carpets, etc.) may cause the toy to stop working. If this happens, re-install batteries to reset the toy.
- In an environment with radio frequency interference, the product may malfunction. If this happens, re-install batteries to reset the toy.

## FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference and
- (2) this device must accept any interference received, including interference that may cause undesired operation. **WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. **NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna
  - Increase the separation between equipment and receiver
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

© [2019] viacom international Inc. All Rights Reserved. Nickelodeon, Teenage Mutant NinjaTurtles, and all related titles, logos and characters are trademarks of Viacom International Inc.

Do Not Discard Packaging. It Contains  
Important Safety Information.



©2019 Super Impulse USA, LLC  
10 Canal Street, Suite 330  
Bristol, PA USA 19007  
Tel.: 267 878 0466  
www.superimpulse.com  
MADE IN CHINA, SHENZHEN

3 x AAA 1.5V  
LR03  
Batteries included.

www.superimpulse.com